




# introduction to thickeners and rheology modifiers

---

Speaker Tour – GGSCT&PNWSCT 2019



Natalia Lopes  
coatings technical service




**Ashland**<sup>™</sup>  
always solving


# why do we need them?

rheology modifiers dictate a paint's application feel and influence final dry film appearance.


- choosing the right rheology modifier results in:
  - smooth finish
  - exceptional sag/level balance
  - high paint stability
  - low VOC
  - excellent wet and dry hiding
  - control and minimization of formulation costs



# thickening mechanisms



Conventional  
(Volume)



Associative  
(Association)

# types of rheology modifiers

	SYNTHETIC	NATURAL DERIVATIVES
CONVENTIONAL	<p>Polyvinyl alcohol</p> <p>Polyacrylamide</p> <p>Polyacrylic acids</p> <p>ASE - <b>A</b>lkali <b>S</b>oluble <b>E</b>mulsion</p>	<p>Cellulose ethers:</p> <p>CMC - <b>C</b>arboxy<b>M</b>ethyl<b>C</b>ellulose</p> <p>HEC - <b>H</b>ydroxy<b>E</b>thyl<b>C</b>ellulose</p> <p>MHEC - <b>M</b>ethyl<b>H</b>ydroxy<b>E</b>thyl<b>C</b>ellulose</p>
ASSOCIATIVE	<p>HM-PAPE - <b>H</b>ydrophobically <b>M</b>odified <b>P</b>oly<b>A</b>cetal <b>P</b>oly<b>E</b>ther</p> <p>HEUR - <b>H</b>ydrophobically Modified <b>E</b>thoxylate <b>U</b>rethane</p> <p>HASE - <b>H</b>ydrophobically Modified <b>A</b>lkali-<b>S</b>oluble <b>E</b>mulsion</p>	<p>HMHEC - <b>H</b>ydrophobically <b>M</b>odified <b>H</b>ydroxy<b>E</b>thyl<b>C</b>ellulose</p>


Others: clays, bentonite...

# associative thickener structures


2<sup>nd</sup> Gen NSAT < 50,000 MW




HASE ~ 500,000 MW




1<sup>st</sup> Gen NSAT < 50,000 MW



HMHEC ~ 350,000 MW



# HEC thickening mechanism



molecular weight




major factor for thickening

# HEC grade selection

Viscosity Grade/Molecular Weight Effects  
60-PVC Vinyl-Acrylic Flat Paint, 95 KU


Thickener	Mw x10 <sup>3</sup>	lbs/ 100 gal	ICI, Poise	Spatter Resistance	Leveling	Sag, mils
High Mw	1,000	3.6 	0.9 	3 	5 	14 
Med Mw	700	4.7 	1.2 	4 	4 	18 
Low Mw	300	9.6 	1.7 	6 	3 	24+ 

# HM-HEC thickening mechanism (in solution)




entanglement and hydrophobic  
association

# HM-HEC thickening mechanism (in paint)





# HEC vs. HM-HEC


70-PVC Vinyl-Acrylic Flat Paint





Thickener	Thickening Efficiency		ICI, Poise	Spatter Resistance	Leveling	Sag, mils	Scrub Cycles
	Wt (%)	lbs/100 gal					
HEC	0.48	5.4	0.6	2	3	24	213
HM-HEC	0.63	7.2	0.9	9	3	18	223



# NSAT associative thickening mechanism



# latex type effects




# standard terminology

---


- two basic functional types of NSATs

## *Low-Shear Effective*




- Stormer KU/Thickening
- More Efficient
- More Shear Thinning/Less Newtonian

## *High-Shear Effective*




- ICI Viscosity
- Less Efficient
- Less Shear Thinning/More Newtonian


# formulating with Aquaflow™ rheology modifiers



# shear rate considerations



# viscosity recovery profiles



2<sup>nd</sup> Gen NSAT viscosity recovery profile allows leveling to proceed while preventing dripping


Sag and Leveling balance

# sag resistance and leveling balance

<50 g/L VOC Acrylic Semi-Gloss Deep Base

Traditional HEUR or NSAT  
rheology modifiers

2<sup>nd</sup> Generation NSAT  
Technology



*This no-drip  
behavior with  
excellent  
leveling is  
typical of  
Next  
Generation  
technology.*


# experimental method

---


- 29 PVC, 29 VS VAE semi-gloss paint
  - HEC
  - NSATs: traditional HEUR, 1<sup>st</sup> & 2<sup>nd</sup> gen. PAPE
- drywall primed using flat black primer
- paints applied with 3/8" nap roller cover
- analyzed panels
  - visual ranking
  - pixel analysis
  - surface profilometry

# visual panel rating


- subjective visual rating of the applied hide of painted drywall panels



# improved visual hide benefits





## The Role of Leveling in Applied Hiding



- deeper brush marks/roller stipple will reduce hiding
- more uniform film thickness will improve hiding

# pixel analysis




- scan substrate → image analysis
- histogram distribution of how “white” is the sample
- quantifiable and more reliable measure to aid product development and benchmarking
- used to also analyze surface defects
  - foam
  - pick spots

# surface profilometer

Nanovea ST500




automated XY-stage – 40cmx20cm scan area  
scan speed: 200mm/s  
line scanner: Z-range 0-1000 mm, (80nm Resolution)




- non-contact method based on axial chromatism technique
- each separate wavelength will re-focus at a different height
- software quantifies various surface roughness parameters


# nap pattern characterization





**EXTREME LOOSE**



**LOOSE**








**TIGHT & UNIFORM**



surface  
profilometer

high resolution  
scanner

# reduced TiO<sub>2</sub> application performance



lower Sq value indicates smoother surface

- paint with PAPE NSAT is whiter than HEC thickened paint
- narrow distribution of pixels towards #256

# conclusions

---


- different chemistries and thickening mechanisms can control paint performance from wet application to dried appearance
- rheology modifiers play a key role in developing in-can feel and application properties resulting in superior applied hide
- visual improvements to applied hide properties can be characterized and quantified with analytical techniques to reduce subjectivity of visual measurements

**Paint properties can be tailored by  
careful selection of the rheology package!**

# acknowledgements

---

- Cathleen Roberts-Howard
- Gina Martinelli
- James Rothka
- Joseph Ambrosi
- Kent Maghacut
- William Hill
  
- Pacific Northwest Society of Coatings Technology
- Golden Gate Society for Coatings Technology



Ashland<sup>TM</sup>  
always solving

# disclaimer

---

The information contained in this presentation and the various products described are intended for use only by persons having technical skill and at their own discretion and risk after they have performed necessary technical investigations, tests and evaluations of the products and their uses. This material is for informational purposes only and describes the scientific support for the use of the products described herein as an ingredient intended to enhance performance of an end product. **Certain end uses of these products may be regulated pursuant to rules governing medical devices or other regulations governing drug uses. It is the purchaser's responsibility to determine the applicability of such regulations to its products.** While the information herein is believed to be reliable, we do not guarantee its accuracy and a purchaser must make its own determination of a product's suitability for purchaser's use, for the protection of the environment, and for the health and safety of its employees and the purchasers of its products.

Neither Ashland nor its affiliates shall be responsible for the use of this information, or of any product, method, formulation, or apparatus described in this brochure. Nothing herein waives any of Ashland's or its affiliates' conditions of sale, and no statement, information and data is to be taken as a guarantee, an express warranty, or an implied warranty of merchantability or fitness for a particular purpose, or representation, express or implied, for which Ashland and its affiliates assume legal responsibility. We also make no warranty against infringement of any patents by reason of purchaser's use of any information, product, method or apparatus described in this presentation.

The testing information (the "Testing Information") has been gratuitously provided by Ashland. The Testing Information is based on many factors beyond Ashland's control, including but not limited to, the conditions prevailing when the testing was conducted, and in some cases, is based on data generated with development samples of the Active Ingredient. Although it is intended to be accurate, ASHLAND DISCLAIMS ANY AND ALL LIABILITY, EITHER EXPRESS OR IMPLIED. The Testing Information is confidential or proprietary to Ashland, and may not, except as provided below, be disclosed to any third party. You may not make commercial use of the Testing Information, or make claims with respect to your products based the Testing Information, without the written agreement with Ashland covering such use.

® Registered trademark, Ashland or its subsidiaries, registered in various countries

™ Trademark, Ashland or its subsidiaries, registered in various countries

\* Trademark owned by a third party

© 2015, Ashland

